


<b>DTC</b>	<b>P0768/65</b>	<b>Shift Solenoid D Electrical Malfunction (No. 4 Solenoid Valve)</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

No. 4 solenoid valve is controlled by Engine and ECT ECU and it switches ON and OFF of the O/D direct switch.


DTC No.	DTC Detecting Condition	Trouble Area
P0768/65	<p>The Engine and ECT ECU checks for an open or short circuit in the No. 4 solenoid valve circuit when it changes.</p> <p>The Engine and ECT ECU records DTC P0768/65 if condition (a) or (b) is detected once, but it does not light up CHK ENG.</p> <p>After Engine and ECT ECU detects condition (a) or (b) continuously 8 times or more in 1 trip, it causes the CHK ENG lights up until condition (a) or (b) disappears.</p> <p>After that, if the Engine and ECT ECU detects condition (a) or (b) once, it starts lighting up CHK ENG again.</p> <p>(a) Solenoid resistance is <math>8\ \Omega</math> or less (short circuit) when the solenoid is energized.</p> <p>(b) Solenoid resistance is <math>100\ \text{k}\Omega</math> or more (open circuit) when the solenoid is not energized.</p>	<ul style="list-style-type: none"> <li>• Open or short in No. 4 solenoid valve circuit</li> <li>• No. 4 solenoid valve</li> <li>• Engine and ECT ECU</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check transmission wire.

**PREPARATION:**

Disconnect the transmission wire connector.

**CHECK:**

Measure resistance between S4 of transmission wire and body ground.

**OK:**


Resistance: 11 – 15  $\Omega$  at 20°C (68°F)

OK

Go to step 3.

NG

## 2 Measure resistance between terminals S4 of Engine and ECT ECU and body ground.

**PREPARATION:**

(a) Remove the Engine and ECT ECU hood.

(b) Disconnect the connector from Engine and ECT ECU.

**CHECK:**

Measure resistance between terminals S4 and E1 of Engine and ECT ECU.

**OK:**

Resistance: 11 – 15  $\Omega$  at 20°C (68°F)


OK

Check and replace the Engine and ECT ECU (See page N-34).

NG

Repair or replace the harness or connector (See page N-34).

### 3 Check No. 4 solenoid valve.



#### PREPARATION:

Remove the No. 4 solenoid valve (See page AT-14).

#### CHECK:

- Measure resistance between terminal and solenoid body.
- Connect positive (+) lead to terminal of solenoid connector and negative (-) lead to solenoid body.

#### OK:

- Resistance: 11 – 15 Ω at 20 °C (68 °F)
- The solenoid makes an operating noise.

NG

Replace the No. 4 solenoid valve.  
(See page AT-14)

OK

Repair or replace the transmission wire  
(See page AT-9)