

CIRCUIT INSPECTION

| | | |
|------------|--------------|---|
| DTC | P0705 | Transmission Range Sensor Circuit Mal-function (PRNDL Input) |
|------------|--------------|---|

CIRCUIT DESCRIPTION

The park/neutral position switch detects the shift lever position and sends signals to the ECM.

| DTC No. | DTC Detection Condition | Trouble Area |
|---------|---|--|
| P0705 | (2-trip detection logic) <ul style="list-style-type: none"> • All switches are OFF simultaneously for NSW, R, N, D, 3 and 2 positions. • 2 or more switches are ON simultaneously for NSW, R, D, 3 and 2 positions. | <ul style="list-style-type: none"> • Open or short in park/neutral position switch circuit • Park/neutral position switch • ECM |

MONITOR DESCRIPTION

These DTCs indicate a problem with the park/neutral position switch and the wire harness in the park/neutral position switch circuit.

The park/neutral position switch detects the shift lever position and sends a signal to the ECM.

For security, the park/neutral position switch detects the shift lever position so that engine can be started only when the shift lever is in the P or N position.

The park/neutral position switch sends a signal to the ECM according to the shift position (NSW, R, D, 3 or 2).

The ECM determines that there is a problem with the switch or related parts if it receives more than 1 position signal simultaneously. The ECM will turn on the MIL and store the DTC.

MONITOR STRATEGY

| | | | | | |
|-----------------------------|------------------------------|--|--|--|--|
| Related DTCs | P0705 | Park/neutral position switch/Verify switch input | | | |
| Required sensors/Components | Park/neutral position switch | | | | |
| Frequency of operation | Continuous | | | | |
| Duration | Condition (A) | 2 sec. | | | |
| | Condition (B) | 60 sec. | | | |
| MIL operation | 2 driving cycle | | | | |
| Sequence of operation | None | | | | |

TYPICAL ENABLING CONDITIONS


| Item | Specification | |
|--|---------------|------------------|
| | Minimum | Maximum |
| The monitor will run whenever this DTC is not present. | | See page DI-1128 |
| Ignition switch | | ON |
| Battery voltage | | 10.5 V or more |

TYPICAL MALFUNCTION THRESHOLDS


| Detection criteria | Threshold |
|---|-----------|
| One of the following conditions is met: Condition (A) or (B) | |
| Condition (A) | |
| Number of the following signal input at the same time | 2 or more |
| NSW switch | |
| R switch | |
| D switch | ON |
| 3 switch | |
| 2 switch | |
| Condition (B) | |
| All of following conditions are met | |
| N switch | |
| NSW switch | |
| R switch | |
| D switch | OFF |
| 3 switch | |
| 2 switch | |

COMPONENT OPERATING RANGE

| Parameter | Standard value |
|------------------------------|--|
| Park/neutral position switch | The park/neutral position switch sends only one signal to the ECM. |

WIRING DIAGRAM**Double Cab:**

Except Double Cab:



INSPECTION PROCEDURE

HINT:

According to the DATA LIST displayed by the OBD II scan tool or hand-held tester, you can read the value of the switch, sensor, actuator and so on without parts removal. Reading the DATA LIST as the first step of troubleshooting is one method to shorten labor time.


- (a) Warm up the engine.
- (b) Turn the ignition switch off.
- (c) Connect the OBD II scan tool or hand-held tester to the DLC3.
- (d) Turn the ignition switch to the ON position.
- (e) Push the "ON" button of the OBD II scan tool or the hand-held tester.
- (f) When you use the hand-held tester:
Select the item "DIAGNOSIS / ENHANCED OBD II / DATA LIST".
- (g) According to the display on the tester, read the "DATA LIST".

| Item | Measurement Item/ Range (display) | Normal Condition | Diagnostic Note |
|--------------|--------------------------------------|---|---|
| PNP SW [NSW] | PNP SW Status/ ON or OFF | Shift lever position is; P and N: ON Except P and N: OFF | When the shift lever position displayed on the hand-held tester differs from the actual position, adjustment of the PNP switch or the shift cable may be incorrect. |
| LOW | PNP SW Status/ ON or OFF | <ul style="list-style-type: none"> • Shift lever position is 2: OFF ↓ • Shift position L switch Push: ON ↓ • Shift position L switch Push: OFF | ↑ |
| 2ND | PNP SW Status/ ON or OFF | Shift lever position is; 2 and L: ON Except 2 and L: OFF | ↑ |
| 3RD | PNP SW Status/ ON or OFF | Shift lever position is; 3: ON Except 3: OFF | ↑ |
| DRIVE | PNP SW Status/ ON or OFF | Shift lever position is; D: ON Except D: OFF | ↑ |
| REVERSE | PNP SW Status/ ON or OFF | Shift lever position is; R: ON Except R: OFF | ↑ |

| | |
|---|--|
| 1 | Inspect park/neutral position switch. |
|---|--|

Switch Side:

(Connector Front View):



D14154

PREPARATION:

- Jack up the vehicle.
- Disconnect the park/neutral position switch connector.

CHECK:


Measure the resistance according to the value(s) in the table below when the shift lever is moved to each position.

OK:

| Shift Position | Tester Connection | Specified Condition |
|----------------|-------------------|---------------------|
| P | 2 – 6 and 4 – 5 | Below 1 Ω |
| Except P | ↑ | 10 kΩ or higher |
| R | 2 – 1 | Below 1 Ω |
| Except R | ↑ | 10 kΩ or higher |
| N | 2 – 9 and 4 – 5 | Below 1 Ω |
| Except N | ↑ | 10 kΩ or higher |
| D | 2 – 7 | Below 1 Ω |
| Except D | ↑ | 10 kΩ or higher |
| 3 | 2 – 3 | Below 1 Ω |
| Except 3 | ↑ | 10 kΩ or higher |
| 2 | 2 – 8 | Below 1 Ω |
| Except 2 | ↑ | 10 kΩ or higher |

**Replace park/neutral position switch
(See page [AT-11](#)).**

2

Check harness and connector (Park/neutral position switch – ECM).**ECM:****PREPARATION:**

- Connect the park/neutral position switch connector.
- Turn the ignition switch ON.

CHECK:

Measure the voltage according to the value(s) in the table below when the shift lever is moved to each position.

OK:

| Shift Position | Tester connection | Specified condition |
|----------------|---------------------------------|---------------------|
| P and N | E6 – 8 (STAR/NSW) – Body ground | Below 2 V |
| Except P and N | ↑ | 10 to 14 V |
| R | E4 – 11 (R) – Body ground | 10 to 14 V* |
| Except R | ↑ | Below 1 V |
| D | E4 – 21 (D) – Body ground | 10 to 14 V |
| Except D | ↑ | Below 1 V |
| 3 | E4 – 19 (3) – Body ground | 10 to 14 V |
| Except 3 | ↑ | Below 1 V |
| 2 and L | E4 – 10 (2) – Body ground | 10 to 14 V |
| Except 2 and L | ↑ | Below 1 V |

HINT:

*: The voltage will drop slightly due to lighting up of the back up light.

NG

**Repair or replace the harness or connector
(See page [IN-30](#)).**

OK

Replace the ECM (See page [SF-82](#)).